



Temporary Detection

Temporary systems of smoke or heat detection are frequently utilized during construction to cover an area under construction or demolition. The items following are needed to review the temporary system:

- Floor plan with temporary device location.
- Manufacturer catalog “cut sheet” and/or specification for devices used.
- “Impairment Letter” describing occupancy, scope of work, and steps taken to provide a fire-safe environment.
- Copy of BFD Construction/Demo Permit.
- Copy of BFD Sprinkler Permit, if applicable.

Contact one of the Boston Fire Department Fire Protection Engineers for more information, 617-343-2043.